

A

Simbols	Unit of measures	Description
A_{c1}	[N]	Calculated thrust load at gearbox input shaft
A_{c2}	[N]	Calculated thrust load at gearbox output shaft
A_{n1}	[N]	Rated thrust load at gearbox input shaft
A_{n2}	[N]	Rated thrust load at gearbox output shaft
A_{r2}	[N]	Thrust load at gearbox output shaft