

M

| Simbols | Unit of measures | Description |
|----------------|-------------------------|-------------------------------------|
| M_2 | [Nm] | Torque delivered to output shaft |
| M_{2max} | [Nm] | Gearbox max. output torque |
| M_A | [Nm] | Mean breakaway torque |
| M_b | [Nm] | Rated brake torque |
| M_B | [Nm] | Brake torque |
| M_{c2} | [Nm] | Calculated torque at gearbox output |
| M_L | [Nm] | Counter-torque during acceleration |
| M_N | [Nm] | Rated torque |
| M_{n2} | [Nm] | Gearbox rated output torque |
| M_{r1} | [Nm] | Required torque at gearbox input |
| M_{r2} | [Nm] | Required torque at gearbox output |
| M_S | [Nm] | Starting torque |